

Mighty User Guide

fetch

Welcome to Fetch


Handy Tips	4
Watching Live TV	8
Using the TV Guide	12
Recording TV	15
Managing your Recordings	19
Watching Shows	25
Adding more Channels	28
Watching Movies	30
Watching Apps	35
Watching Sport	44
Watching live PPV events on TV	46
Continue Watching from My Stuff	47
Settings including Parental Controls	49
Pair a Bluetooth Device	52
The Remote Control	55


Welcome to Fetch

Welcome to Fetch, your one-stop non-stop world of entertainment. This user guide shows you tips and tricks to help you get the most out of your service, so you can enjoy all your entertainment in one place.

Home screen

Everything you do on your Fetch Mighty starts from this Main Menu screen.


Press  on your Fetch remote control to bring up the main menu.



1 Handy Tips


Here are a few handy tips to get you started.






Most used buttons




Actions


Actions are available on most screens. They tell you how to use the buttons on your remote to access key features.




- To access actions press .
- To record a program on now or later press , go to show, and press .
- To enable a series recording press  twice.
- To set a reminder press .


Tips

 Brings up the main menu from any screen.

Use  to navigate anywhere on your Fetch Mighty.

Press  to select.

Press  to show on screen actions.

Go back to previous screen by pressing .





- **Other ways to control your Fetch box**
You can also navigate Fetch from your mobile phone or tablet if you've installed the Fetch Mobi App (Page 49) or through your voice if you have a Fetch Voice Remote (Page 6) paired with your Fetch Mighty.
- **Universal Remote**
You can set up your remote to control your TV via the Universal Remote Set Up (Page 55).
- **Using your PIN**
Various functions, including anything that requires a purchase, prompts you to enter a PIN. (You may want to keep this a secret from your children).


How To videos

You can watch videos about key features to get the most from your service at [Menu > ⚙ > How To](#).

Search

You can easily search for things to watch by keyword from the program name, synopsis, or cast and crew. Search covers Free-to-Air and subscription channels, TV Apps, TV Store, Movie Store, Movie Box, recordings, and streaming apps like Prime Video, Netflix, YouTube, Stan and Paramount+. Search currently doesn't cover the Optus Sport, Eros Now, YuppTV, Acorn TV, iwonder, Vimeo or Kidoodle.TV apps. To search these you will need to do this within the individual apps.

- 1 Use  to select  and press .
- 2 Use the on screen keyboard to type.
- 3 Search starts automatically when you type one or more character.
- 4 To see all results, select [Full Search](#) or scroll to the end of the results carousel and choose [View More](#).
- 5 Highlight a search result and press  to view the info.
- 6 If there are a few ways to watch, we'll let you know so you can pick what's best for you.




Tips

Extend your search

If you don't see the results you want, you can widen your search. Scroll down to the end of the search results. Select [Extended Search](#) to search by the program description, or [YouTube](#) to continue your search on YouTube content.


Voice Search and Voice Control

You can easily search and control Fetch using a Fetch voice remote (Page 56). You will need to pair the remote to your Fetch Mighty using Bluetooth before this will work.

- 1 On your remote, hold down the voice button .
- 2 If you haven't paired the remote yet, you'll see a pairing prompt. Once paired, repeat step 1.
- 3 When you see the on screen prompt "I'm Listening" keep holding the voice button and speak into the remote.
- 4 You can ask Fetch to do something, like "Fetch popular movies" or "Play BBC First". To launch a program, channel or app you can just say the name, like "Bluey", "Discovery Turbo" or "Netflix".
- 5 If there are multiple results, Fetch will open them in the [Search](#) screen.



Tips

- If your spoken phrase wasn't recognised, try again and speak clearly.
- If you press  without holding down the button this will launch the Search.

Note


The included remote varies depending on where you got your Fetch Mighty. The Voice Remote is available for purchase at fetch.com.au/voice.

Here’s a list of some of the things you can say:


	Voice Command	What it does
Change channels:	“Fetch BBC First” or just “BBC First”	Launches BBC First channel
	“Play Discovery Turbo”	Launches Discovery Turbo channel
	“Seven HD”	Launches 7HD channel
Control playback:	“Pause”	Pause playback
	“Play”	Resume playback
	“Rewind eight times”	Rewind playback eight times
	“Fast forward”	Fast forward playback
Search for content:	“Fetch Masterchef” or just “Masterchef”	Launches a Search on Fetch for this title
	“Search YouTube for funny videos”	Launches a Search of YouTube
	“Harry Potter and the Order of the Phoenix”	Launches a Search on Fetch for this title
	“Search for The Expanse on Prime Video”	Launches the title on Prime Video
	“Search for The West Wing”	Launches a Search and shows all ways to watch this title
Launch an app:	“Fetch Netflix” or just “Netflix”	Launches Netflix
	“Open Prime”	Launches Prime Video
	“Go to SBS on Demand	Launches SBS on Demand
Navigate Fetch:	“Fetch recordings” or just “Recordings”	Opens Menu > My Stuff > Recordings
	“Open TV Guide”	Opens Menu > Guide
	“Go to Movie Store”	Opens Menu > Movies > Store
	“Movie Box”	Opens Menu > Movies > Movie Box
	“Open Settings”	Opens Menu > ⚙


Note

While you can launch apps through voice commands, you can’t control or search using voice commands within apps. You can only search for Netflix Exclusive Content through text entry, voice search isn’t supported for this content.

For more voice commands hold  and say “Voice Help”.

2 Watching Live TV

To watch Free-to-Air or Subscription TV channels, press  then go to [Guide](#) to select the channel you want to watch.

If you have been in any other area of the Fetch service you can go back to watching TV by pressing .






Channel Switch




Use these up and down buttons to move between channels.




Watch Live TV - Channel List

While watching Live TV use  to see at a glance what's playing on other channels. Press  to go forward or back. If you find something you like press  to launch the channel.



Watch Live TV – Information Bar

While watching Live TV the Information Bar appears anytime you change channel or when you press **Info** on your remote.



You can go forward in the Info Bar to see what’s coming up or back to catch up on shows you’ve missed.

Press **Info** twice to see more detail on the highlighted show or to access options to record.
The Info Bar will disappear after about 5 seconds, or you can press Info again to remove it immediately.



Closed Captions

When you see this symbol **CC** on a program from the Information Bar, it means there are Closed Captions available.

To turn on Closed Captions while watching a TV channel, press **Text** on your remote. Repeat to turn off Closed Captions again. On some remotes you may need to press **123...** first and then press **Text Info**.



Watch from Start




If you’re late to a show and see **Watch from Start** it means you can press the green button to replay the show from the beginning.

Pause, Play and Rewind Live TV

When you start watching a channel, your Fetch Mighty automatically starts storing the channel for up to 3 hours at a time. So you can pause, rewind, fast-forward as much as you like within this time, as long as you stay on the same channel. You'll see this from the Info Bar as a light blue line below the program info.



Pause a program you're watching now

You can pause a TV program you're watching and resume anytime within the next 3 hours. If you change channels you won't be able to resume the paused channel.

- 1 Press  .
- 2 Press  again to resume watching.
- 3 To exit Pause Live TV press  .



Rewind live TV

You can rewind live TV back to the point where you started watching the channel.

- 1 Press  for 2x speed, press it again to go faster.
- 2 Press  to start watching again.






Fast forward paused live TV


When you have paused or rewound live TV you can fast forward it until you catch up to the live stream.


- 1 Press  for 2x speed, press it again to go faster.
- 2 Press  to start watching again.

Last Watched

You can jump back to something you were watching previously, anywhere on Fetch – including channels, episodes and movies. For recordings, programs on TV Apps and purchases from the Store, you can go straight back to the program you were watching. For streaming apps like Netflix or Prime Video, you can launch the app to find what you were watching previously through the app.

- 1 While watching TV, press  . You'll see a carousel with the last 12 items you watched on Fetch.
- 2 Use  to select an item and press  to watch.
- 3 To close and go back to what you were watching press  or  .







You can remove items from the [Last Watched](#) carousel, by pressing  .

3 Using the TV Guide


The TV Guide is the easiest place to find what you want to watch right now, or record for later. You can move forwards and backwards through the TV Guide, to go back and find shows that already aired. Set up Favourites to easily see what's on the channels you watch most.

See what's on and coming up

- 1 Press  on the remote or select **Guide** from the main menu.
- 2 Press  or  to skip forward and back a day in the TV Guide.
- 3 Press  to find channels and programs in the TV Guide.


Switch between list and grid view

Go to **Menu > ⚙ > User Preferences > TV Guide** to change your preferred TV Guide view.



TV Guide List View




View one channel at a time



TV Guide Grid View

View all channels and programs at a time




- Movies on TV are flagged with the movie icon .
- Programs with  are ready to watch anytime, like virtual playlist channels and shows that aired and are available to re-watch.
- Press  on your remote for program info. To change your TV Guide preferences, see Page 51.

TV Guide – Reverse EPG

You can go back a day in the TV Guide and watch programs you missed.

- 1 In the TV Guide or Live TV Info Bar press ◀▶ to browse backwards into the reverse EPG. Programs available to re-watch have a play icon ▶.
- 2 Press 🐾 to watch or press Info for program options.
- 3 If there are more ways to watch the show we'll let you know. The options vary by content availability, and may include watching a recording or playing the program on an app.



Set Reminders

You can set a reminder to alert you when your favourite programs are about to start.

- 1 In the TV Guide or Live TV Info Bar, highlight the program you want a reminder for and press 📺 or press 🐾 to set a reminder through the Options menu.
- 2 A ⌚ will appear beside programs with a reminder. Repeat the above step to cancel a reminder.

Favourites

Favourites let you set up your TV Guide to group your favourite channels at the top of the guide, so you can quickly see what’s playing on the channels you watch most.


There are **two** ways to add channels to Favourites.


- 1 In Settings
- 1

Open the Settings area at [Menu > ⚙️](#).
- 2


Go to [Channels > Manage Channels](#) and select the channels you want to add to Favourites.
- 2 From the Info Bar or Guide
- 1


Open the Guide or Info Bar.
- 2

Press .
- 3

To remove a channel from Favourites press .

Finding your Favourites

- 1 In the Guide, press  to jump to the top where your Favourites are pinned.
- 2 In the Live TV Channel List (Page 8) scroll down to find your Favourites grouped at the bottom.



Hide channels

You can hide channels that you don’t want to appear in your TV Guide. Go to [Menu > ⚙️ > Channels > Manage Channels](#) and check the channels you want to hide.



4 Recording TV

The Fetch Mighty box allows you to record Free-to-Air TV and any other channels that you are subscribed to. It has space for up to 585 hours of HD recordings, and you can record individual episodes of a show, or set a Series Recording to automatically record every episode of a show.

Four ways to set a recording








There are four ways to set a recording using your remote control.

1 From the Info Bar

When you are watching a show and decide you want to record it press  to display the Info Bar. Then press  once to set a recording and twice to set a Series recording.

2 From the TV Guide

Go to [Menu > Guide](#) to see all your channels and set recordings using the steps shown below.

- 1 Use   to find the channel and program you want to record.
- 2 To record press . To set a Series Recording (if available for that show) press  twice. To cancel press .
- 3 Press  to display recording options.
- 4 To set a Team Recording (if available for a match) select [Set Recording](#), and then [Team Recording](#) and press . Select your team then [Save & Close](#).








You can watch shows on virtual playlist channels like the Free-to-Air TV App channels (Page 41) or the Oxygen subscription TV channel anytime. So, you won't see recording options on these channels.


3 Using Featured TV

There are loads of shows available on TV that you can record to watch at any time. **Featured TV** makes it easy to find upcoming shows and set recordings.

Go to **Menu > Shows**.

- 1 Select **Featured TV** and press .
- 2 Use  to explore shows on today, tomorrow or later in the week.





Press  to view the show info and options.
- 3 Find the show you want to record, highlight **Set Recording** and press .
- 4 Change the options if you wish, then select **Save & Close** and press .





4 From the movie or show details screen

You can set a recording for a show or movie available on a TV channel from the details screen.

Go to **Menu > Shows** or **Menu > Movies**.

- 1 Use  to explore titles.
- 2 Press  to view the info and options.
- 3 Select **Record** and press .
- 4 Change the options if you wish, then select **Save & Close** and press .



Recording multiple shows at the same time

How many programs can you record at a time?

The number of channels you can record at the same time depends on which Fetch box you have, whether you are recording Free-to-Air or Subscription channels, and what your bandwidth settings are.

The **Mighty Fetch box** has 4 tuners – three for recording and one for watching, and can record up to six channels while you watch a seventh. Each of the three recording tuners in this box can record 2 Free-to-Air channels from the same channel family at the same time.

The **Gen 2 Fetch box** has 3 tuners – two for recording and one for watching, and can record up to four channels while you watch a fifth. Each of the two recording tuners in this box can record 2 Free-to-Air channels from the same channel family at the same time.

If you have an additional **Fetch Mini** in your home for Multiroom, you can set and manage recordings remotely on your connected Fetch Mighty or Gen 2 box from the Fetch Mini. All boxes need to be on the same account, powered on and connected to the same home network.

Here’s more info on how channel groups work:

Free-to-Air channels are made up of groups as shown here:

Seven Group



Nine Group



ABC Group



Ten Group



SBS Group



* Available in Metro areas and some Regional areas.

** Available in Metro areas only.



Each tuner in the Gen 2 and Mighty boxes can record two channels from the same group at the same time. For example, on the Mighty you can record 2 shows from the Ten group, 2 from the Seven group and 2 from the ABC group all at the same time, while you're watching another channel.


There are no channel groups for subscription channels. You can record any 2 subscription channels on Gen 2 or any 3 subscription channels on the Mighty at the same time.

The number of subscription channels you can record at a time also depends on the bandwidth limit in User Preferences (Page 50).

Recording conflicts

A recording conflict arises when you try to schedule too many recordings at the same time.

- 1 When you schedule a recording that creates a conflict, you will be prompted to cancel one of the recordings.
- 2 Select **Stop** next to a recording you want to cancel and press  .
- 3 Select **Confirm Recording** to go ahead, or press  to close without stopping existing recordings.



5 Managing your Recordings

Finding your recordings

You'll find all your TV recordings at [Menu > My Stuff](#).







- Access your most recent recordings via the [Recent Recordings](#) carousel.
- To find all your recordings, go to [Menu > My Stuff > Recordings](#).

We automatically save all episodes of the same show together and display the program name.

To watch a recording, select the program and press . Then select the episode you want to watch and press .

Recording Icons

You will see different icons next to recordings in your recordings list. Here's what they mean.

 (red) Currently Recording	 Episode not yet watched
 Series or Team Recording	 Part Watched
 Protected	 Fully Watched



To record all live games your favourite sports team plays, go to [Menu > Sport](#) (Page 45). Team recording is available for selected sporting events on Fetch. You can find and manage your Team Recordings in [Sport](#) or [My Stuff > Recording Priority](#).

Multiroom

Watch recordings on another Fetch box

You can share recordings between up to three Fetch boxes in your home if your Fetch service includes the Multiroom feature*. This means you can watch stuff you recorded on any Fetch box from any other box in your home. You can watch content recorded on your other boxes from a Fetch Mini too.

You can't set or manage recordings on other boxes from a Fetch Mighty or Gen 2 box. However, you can do this from a Fetch Mini when you pair to your Fetch Mighty or Gen 2 box.

Finding your shared recordings

You'll see shared recordings in [Menu > My Stuff > Recordings](#). The name of the Fetch box on which the recording is stored will show in the recording options.

How does Multiroom work?

All your Fetch boxes need to be on the same account, powered on and connected to your local network.

Select the sharing options in [Menu > ⚙ > Multiroom > Options](#) (Page 51) for each box in your home. You can then share recordings, subscription channels, rentals and purchases.

If you've no antenna connected to your Fetch Mini, you can share Free-to-Air channels from a paired Mighty or Gen 2 box. (Your paired Fetch Mighty still needs a TV antenna connection to receive and share digital Free-to-Air TV). You can't share Free-to-Air channels from one Fetch Mighty or Gen 2 box to another.

Which boxes support Multiroom?

The Gen 2, Mighty, and Mini boxes all support sharing.

* Multiroom may not be available on your Fetch service yet.

For more info or help, download the Multiroom User Guide from fetch.com.au/guides


Things you can do with Recording Priority

1 Set the seasons you want to record

You can set the season option for a Series Recording to control which episodes to record.

- [Record All Seasons](#) means all episodes from all seasons of the show will be recorded.
- [Record Latest Season](#) means only the latest season onwards will record.
- [Record Newest](#) will only record newer episodes than the latest episode and season onwards. If the episode is already on your Fetch box it won't record again. You may still get duplicate recordings if the correct season or episode info is unavailable.

When setting a Series Recording from the TV Guide press  twice. Then press . Select [Modify Recording](#), and then [Series Recording](#). Change the seasons setting using the on screen arrows.



2 Set the number of episodes you want to keep





You can choose the number of recorded episodes of a show you want to keep on the hard drive.


- If it's the evening news you may just want to [Keep most recent episode only](#) (record today's and delete yesterday's) or you can choose to keep 2 or 5 most recent episodes.
- [Protect Recordings - Off](#) means the recordings will be kept unless the box needs space for more recordings.
- [Protect Recordings - Keep All](#) means the recordings will never be deleted unless you manually delete them. We don't recommend you use this option for all your series recordings as it can fill up your Fetch box.

3 Set priorities of Series and Team Recordings

Sometimes you might schedule more than the allowed number of recordings to occur at the same time (Page 18). You can prioritise your Series and Team Recordings so if this happens, your preferred shows get recorded.







To do this go to [Menu > My Stuff > Recording Priority](#).


- 1 Use  and  to permanently pin your favourite programs to the top. New Series and Team Recordings will automatically be added below the pinned list.
- 2 Use the on screen arrows and  to move programs up or down the list.
- 3 Press  to reschedule today's recordings.



Protecting your recordings


You can protect important recordings from being deleted by using the Protect Recording feature. Go to your recordings, select [Modify Recording](#) and [Protect Recording – On](#).

- 1 Use   to select a recording.
- 2 Press  to activate the options menu.
- 3 Use   to navigate the options.
- 4 Press  to confirm your selection.





Tips

These steps are for protecting a single recording. To protect recordings that are part of a Series Recording, see Page 21, “2 Set the number of episodes you want to keep”.




Sorting by season and episode

To make recordings easy to find they're grouped by Season and Episode. For more ways to sort recordings, go to [Menu > My Stuff > Recordings](#). Highlight a recording then press .

If you set up a Series Recording to Record All Seasons, the box will record every episode of the show that airs, whatever season it is from. If you're only interested in the most recent seasons highlight the seasons you don't want to keep in your recordings list and delete them by pressing . To change the season option, see Page 21, “1 Set the seasons you want to record”.

Deleting and restoring recordings




You don't need to worry about your Fetch Mighty filling up. It will delete old recordings that are not protected if it needs more space. But, if you'd like to delete a recording or folder highlight it and press .


If you delete a recording by mistake, go to [My Stuff > Recently Deleted](#) to restore it. Fetch also moves recordings here and deletes them permanently when it needs to make more space on your box for new recordings.

6 Watching Shows



You can browse all shows available on Fetch in one place. When you find a show you like, you can see all ways to get the show on Fetch – including on streaming services, TV apps, or via the Store.

Go to [Menu > Shows](#).


- 1 Select [Shows](#) from the main menu and press .
- 2 Use  to browse shows in carousels. To see more items, scroll to the end of the carousel and select the [View All](#) option.
- 3 Use the [Shows](#), [Store](#), and [Featured TV](#) tabs to help you find shows.
- 4 Select a show and press  to view the info and options available.





What you can do from the show details

Press  to read the full synopsis. To see [cast and crew](#) info or [reviews](#), use  to scroll down the screen.

To add the show to [My Stuff > My Shows](#) highlight [+ My Stuff](#) and press .








We'll show you the main way to watch the show by default. Playback options vary based on content availability. You can [buy](#) a season or episode or [record](#) the show on TV, if available. For more ways to watch, highlight [Ways To Watch](#) and press . You need a subscription to watch on apps like Netflix or Stan.






Buy a show from the Store

In the Store you can buy individual episodes or full seasons of some of the most popular TV shows. TV shows can't be rented. When you buy a TV episode or season you are buying the right to watch it as often as you like on your current Fetch subscription with your current Fetch Service Provider.

Go to [Menu > Shows > Store](#).

- 1 Use   to select a show and press .
- 2 To buy an episode rather than the whole season, use   to highlight [Episodes](#) and press . Choose the episode you'd like to purchase.
- 3 To buy an episode or season, you'll be asked to enter your Parental PIN and press . You can choose to buy the SD or HD format if available. Once you confirm the purchase the amount will come off your credit card for Fetch retail customers or will be added to your next month's bill from your Fetch Service Provider.
- 4 If your purchase is successful the first available episode will download ready to play.



Tips

To find shows you purchased from the [Store](#), go to [Menu > My Stuff](#). You'll see your most recent purchases in the [My Purchases & Rentals](#) carousel, or find all your purchases at [My Stuff > My Shows](#) (see Page 48).

Cost to buy TV episodes and seasons

TV episodes cost \$3.49 for HD and \$2.99 for SD. The price will vary on occasion when specific sales might be on.

Season prices will vary depending on how many episodes are in the season, but you do save money buying the whole season rather than the individual episodes.

Episode purchases don't count towards a Season purchase, so if you think you want to watch the whole season it's better to buy it all at once.

Note

Look for [Try first episode free](#) on the show details or go to [Shows > Store](#) and browse the [First Episode Free](#) carousel.


7 Adding more Channels

Bite-sized channel packs can be added on a month-to-month basis. You can add one or multiple packs, with 5 to choose from:

- Kids Pack (7 channels)
- Vibe Pack (8 channels)
- Variety Pack (10 channels)
- Knowledge Pack (18 channels)
- Ultimate Pack (40+ channels, including all of the channels from the above packs)

*Channels and content subject to change.

How to add a pack



- 1 Select **Add More** from the main menu.
- 2 Use to see available packs. Press to select pack. Explore channels in pack using .
- 3 Press to subscribe to a pack.
- 4 To unsubscribe, press . Subscriptions on channel packs are for a minimum of 1 month.

The minimum contract term on each pack is 1 month, and you can add or remove them at any time with no ongoing costs.

Note

You need a current subscription to a channel pack to watch recordings made on a channel too.

Channel Packs

What's the Entertainment Pack?

The Entertainment Pack is an old add-on channel pack no longer available. If you are subscribed to this pack, you can stay on this if you wish, but if you remove it, you can't add it again.

What's in the Ultimate Pack?

Upgrade to the Ultimate Pack for all the Entertainment channels and more. The Ultimate Pack includes all four Skinny Packs: Vibe, Variety, Knowledge, and Kids.

If you prefer, you can also add just one or two Skinny Packs rather than the Ultimate Pack. If you try to add all Skinny Packs, we'll prompt you to get the Ultimate Pack as this is more cost-effective.

If you have the Entertainment Pack, you'd need to remove it before you can upgrade to the new Ultimate or Skinny Packs.

For more info on available channels, go to: fetch.com.au/packages




Can I downgrade from the Ultimate Pack?


To downgrade from the Ultimate Pack to one or more Skinny Packs, you'd need to remove the Ultimate Pack first. You can then add just the Skinny Packs you want.

8 Watching Movies



You can browse all movies available on Fetch in one place. When you find a movie you like, you can see all ways to get the movie on Fetch – including on streaming services, TV apps, or via the Store.

Go to [Menu > Movies](#).


- 1 Select [Movies](#) from the main menu and press .
- 2 Use  to browse movies in carousels. To see more items, scroll to the end of the carousel and select the [View All](#) option.
- 3 Use the [Movies](#), [Store](#), [Movie Box](#), and [All](#) tabs to help you find movies.
- 4 Select a movie and press  to view the info and options available.




What you can do from the movie details

Press  to read the full synopsis. To see [cast and crew](#) info or [reviews](#), use  to scroll down.

To add the movie to [My Stuff > My Movies](#), highlight [+ My Stuff](#) and press .

We'll show you the main way to watch the movie by default. Playback options vary based on content availability. You can [Rent or Buy](#) movies or [Record](#) if they're available on TV. For more ways to watch, highlight [Ways To Watch](#) and press . You will need a subscription to watch on apps like Netflix or Stan.



Buy or rent movies from the Store

The Movie Store offers over 10,500 movies to buy or rent, ready to watch whenever you want. The cost of movies you rent or buy will be added to your Fetch Service Provider account. When you buy or rent a movie you will be prompted to enter your PIN number.

Go to [Menu > Movies > Store](#).






Renting and buying movies

When you rent a movie from the Store you have 7 days to start watching, and 48 hours to watch from when you first press play. You can watch the movie as often as you want during this time.

When you buy a movie, you are buying the right to watch it as often as you like on your current Fetch subscription with your current Fetch Service Provider.






- On screen Rotten Tomatoes Ratings can help you decide which movies or TV shows to watch.
- You can watch up to 2 items you rented or bought at a time – on a mobile, tablet or Fetch Box. However, you just can't watch the same rented or bought item (movie or TV episode) on more than one device at a time.


- 1 To buy or rent a movie use   to select a movie and press .
- 2 From the movie details screen, you can watch the trailer (if available), rent or buy the movie or add the movie to [My Stuff](#) for later.
- 3 To get a movie you will be prompted to enter your Parental PIN and press .
You can choose to rent or buy the SD, HD, or 4K format if available.
- 4 If your purchase is successful a  will replace the \$ on the title image and the movie will download ready to play.



Finding your movies

There are a few ways you can find your movies:

- To filter movies by those you're entitled to watch, go to [Menu > Movies](#) and press . Select [Free to me](#) and press .



- To find movies you purchased, go to [Menu > My Stuff](#). You can view your most recent purchases in the [My Purchases & Rentals](#) carousel or see all your purchased movies in [My Stuff > My Movies](#), which are marked with a  symbol (see Page 47).



Watching in 4K

You can rent or buy select movies from the Movie Store in 4K Ultra HD. The movie will say **4K** if this is an option.

To watch 4K Ultra HD content on Fetch, you'll need:

- A Fetch Mighty or Fetch Mini 4K connected to a 4K TV
- A steady home broadband speed of 15-25 Mbps
- Video setting set to Auto (4K – 2160P) in [Menu > ⚙ > Audio & Visual](#) (Page 50)

Your TV and home theatre equipment such as an audio video receiver or sound bar, needs HDMI inputs that support 4K and HDMI 2.0/HDCP 2.2 signals. Check your TV or home theatre manual if you need more info.

Watching HDR

You can watch in High Dynamic Range (HDR) on Fetch Mighty or Fetch Mini 4K if your TV supports HDR.

- 1 You'll need to set up HDR on your TV first. Your TV may use a different name for HDR modes like "Ultra" or "Deep Colour" so check your TV manual.
- 2 Then, go to [Menu > ⚙ > Audio & Visual > Advanced > HDR Mode](#) on Fetch to set up HDR.

What can I watch in HDR?


4K movies you rent or buy from the Movie Store are available in HDR, and there is HDR content on Netflix, Prime Video, and YouTube. Currently, you can only watch Netflix in Dolby Vision on the Fetch Mini 4K and Fetch Mighty (4th generation M681T) if the content and your TV supports this. To set up, you'd need to choose [Dolby Vision](#) at [Audio & Visual > Advanced > HDR Mode](#).


Note

To watch Netflix in 4K/HDR/Dolby Vision or Stan in 4K you need a 4K/HDR/Dolby Vision capable Fetch box, and streaming subscription plan that supports 4K. You don't need a subscription to watch YouTube in 4K (Page 36).

Movie Box

Movie Box brings you 30 movies at any time at no extra cost with a new movie added each day. It's not included in all subscriptions so you may need to upgrade your subscription to access it.

- 1 Go to [Menu > Movies > Movie Box](#) and press  to view the movies or go to channel 100.
- 2 Once you've chosen a movie select [Watch](#) to start watching.




9 Watching Apps

You'll find all the apps you can watch on Fetch in one handy place. Includes Streaming and TV Apps, games, screensavers, and utilities like My Media Hub.

Browse all apps

- 1 Select **Apps** from the main menu or press **Apps** .
- 2 Use **◀▶** to browse carousels for the most popular apps on Fetch. The apps will change to show the ones you used the most over the last 30 days first.
- 3 Select the app or show you want to access, then press **🐾** .
- 4 Follow the on screen prompts to use the app.



Note

You'll need a subscription to watch streaming services like Prime Video or Stan. Some Free-to-Air TV Apps may ask you to create an account to watch.

Streaming apps


Fetch makes it easy for you to access YouTube, Plex and Vevo, and your subscriptions to Netflix, Stan, Prime Video, Disney+, Hayu, Paramount+, BritBox, iwonder, Acorn TV, YuppTV and Eros Now on your TV.

Go to [Menu > Apps > Streaming](#).

If you do not have a Netflix, Disney+, Hayu or iwonder subscription you can sign up via the apps on your Fetch box using your remote.

You can sign up to Paramount+ via the app on your box if this option is available on your service.

To get a Prime Video, Stan, BritBox, Acorn TV, YuppTV or Eros Now subscription, you'll need to go to their websites to set up your account, then you can watch on Fetch using your new account details and your Fetch remote.



NETFLIX

- Movies, TV shows and more. Watch anywhere. Cancel at any time.
- Enjoying Netflix on Fetch is easy. If you're already a member, just sign in with your username and password. Not a member? Sign up via the app on your Fetch box using your remote. Your Netflix subscription will be added to your Fetch Service Provider bill or account. Netflix streaming membership required. More information at netflix.com.au.



- Disney+ is the streaming home for entertainment from Disney, Pixar, Marvel, Star Wars, National Geographic, and general entertainment brand Star, which offers the latest from 20th Century Studios, Disney Television Studios, FX, Searchlight Pictures, and more.
- If you already have a Disney+ subscription, log in with your Fetch remote. If you would like to move your existing Disney+ subscription (not billed through Fetch) to your Fetch Service Provider bill or account, follow the same steps below and make sure to enter your existing Disney+ Email and Password. After subscribing through Fetch, direct Disney+ subscriptions will be paused automatically. If your subscription is through a third party platform provider, such as Apple or Google, you will need to manage your subscription directly with those providers.
- Not a member yet? Launch Disney+ on Fetch then select Subscribe and follow the prompts. You'll need to enter your Parental PIN to confirm your subscription. Once subscribed, you will need to activate your Disney+ subscription to start using Disney+ on Fetch. To activate, you can use a mobile device to scan the QR code shown on your box, then enter an Email and Password for Disney+ in your web browser. Alternatively, you can visit fetchtv.com.au/disneyplus, follow the prompts and hit the [Activate Now](#) button to activate your Disney+ subscription. Your Disney+ subscription will be added to your Fetch Service Provider bill or account.



- Watch exclusive Amazon Originals as well as popular movies and TV shows.
- Enjoying Prime Video on Fetch is easy. If you're already a member, follow the prompts to sign in with your Amazon account and register your device.
- Not a member? Visit [Menu > Apps > Streaming > Prime Video](#), select [Register on the Amazon website](#) and follow the prompts. Then visit [PrimeVideo.com/mytv](#) on your web browser to create an Amazon account and register your device. To try one month free, sign up at [PrimeVideo.com/watchonfetchtv](#).
- Amazon account and Prime Video streaming membership required.

Stan.

- Enjoy thousands of hours of entertainment, with first-run exclusives, award-winning TV shows, blockbuster movies and more.
- If you're already a member, just sign in with your Stan username and password.
- Not a member? Try one month free and sign up at [stan.com.au/fetch](#).
- To watch Stan Sport you'll need to add the Stan Sport subscription to your Stan account at [stan.com.au](#). In the app, choose [Sport > Start Watching](#) and follow the prompts to subscribe.



- Download the YouTube User Guide from [fetch.com.au](#) for details on how to use the YouTube App.



- Watch originals, exclusive shows and blockbuster movies.
- If you're already a member, just log in with your username and password.
- Not a member? Try 7 days free and subscribe via the app on your Fetch box using your remote, if this option is available on your service.
- Paramount+ subscription required. More information at [paramountplus.com](#).

Hayu

- Watch your favourite reality shows with thousands of episodes and box sets.
- If you already have a Hayu subscription, sign in with your Fetch remote. You can use the QR code displayed, or go to hayu.com/logintv in your web browser to enter the pairing code.
- Not a subscriber? Open Hayu on Fetch and select [Sign In](#) and then [Register](#) to sign up with your Fetch remote. You'll need to enter your Parental PIN to confirm your subscription. Your Hayu subscription will be added to your Fetch Service Provider bill or account.

britbox

CREATED BY  & 

- Watch the best of British shows including drama, comedy, documentary, lifestyle and more.
- If you're already a member, sign in with your BritBox username and password. Not a member? Try 7 days free and sign up at britbox.com/connect/fetch. Once signed up open BritBox on Fetch and enter the code.

ACORN TV

- Watch world-class crime, thrillers and dramas.
- If you already have an Acorn TV subscription, log in with your Fetch remote.
- Not a subscriber? Sign up by choosing [Start free trial](#), then use the QR code displayed or go to au.acorn.tv/fetch.

iwonder™

- Watch award-winning documentary films, TV series and shorts from various genres.
- Open the iwonder app on Fetch to get a pairing code. If you're already a member, go to iwonder.com/fetchtv to enter the code.
- Not a member yet? Try 14 days free and sign up at iwonder.com/fetchtv. Once signed up, enter the code shown on screen. Then follow the prompts on Fetch to choose a plan and start your free trial. You'll need to enter your Parental PIN to confirm your subscription. Your iwonder subscription will be added to your Fetch Service Provider bill or account.



- One of the world's largest internet-based TV and On-demand service providers for South Asian content, offering over 161+ Hindi channels, 5000+ Movies and 100+ TV shows in 11 languages.
- If you already have a YuppTV subscription, log in with your Fetch remote.
- Not a subscriber? Sign up at yupptv.com/fetchtv. Once signed up, open YuppTV on Fetch to log in.



- Enjoy Bollywood's biggest movie collection. 1000s of Indian hits, exclusive series and originals.
- If you're already a member, select [Login with Eros Now](#) to get a pairing code. Then visit erosnow.com/activate to enter the code shown on screen.
- Not a member? Sign up at erosnow.com. Once signed up, open Eros Now on Fetch to log in.

More streaming apps

Here are some more apps you can access on Fetch:





- Vevo
- Plex
- Vimeo
- Kidoodle.TV


For more info about apps on Fetch see fetch.com.au/features/streaming-apps

TV Apps

If you forget to record something on TV you can watch it on a TV App instead. TV Apps are available for both Free-to-Air and a selection of Subscription TV channels.

Go to [Menu > Apps > TV Apps](#).

- 1 Select the TV App you want to access.
- 2 Use the  to explore. Press  to view episodes and  to play.
- 3 To watch a show later, you can add it to [My Stuff > My Shows](#) by pressing .





Note

- Streaming TV Apps may count towards your broadband usage.
- You may need to sign in to watch a Free-to-Air TV App service. If so, follow the on screen prompts.

Launch TV Apps from the Guide


You can browse or watch a selection of TV Apps as virtual playlist channels, including SBS On Demand, 7plus, 9Now, 10 play, ABC iview, and ABC Kids. You can pause, fast forward and rewind or use the Info Bar to jump to the next or previous shows. You can't record virtual playlist channels as they're not live.

- 1 To watch, go to the channel number, or select [Guide](#) from the main menu and press .
- 2 Use  to navigate down to the TV Apps channels in the guide at channel 180 onwards.
- 3 Select any show or episode to watch.



Tips

You can find shows you watch on these channels at [Menu > My Stuff > My Shows](#).



Music & More apps

You can access music apps, games, and utilities like My Media Hub and screensavers.

Go to [Menu > Apps > Music & More](#)


My Media Hub

You can play video, music and image files from your computer, phone or tablet on your TV using your Fetch box.

The easiest way is to plug a USB into the side of your Fetch box.

If you have a home media server you can also access files wirelessly straight from your computer on your TV using your Fetch box.

For more information, download the My Media Hub User guides for USB and Media Servers from fetch.com.au/guides



More utilities and games

Here are some more utilities and games you can access on Fetch:

- The Weather Network
- Aquarium screensaver
- Fireplace screensaver
- Hangman
- Sudoku
- Sugar Boost


10 Watching Sport

Find and watch sport on live TV channels and apps. This is also where you can set up your Team Recordings (for selected sporting events only) to automatically record every match your favourite team plays.



Go to [Menu > Sport](#).

Watch sport on live TV

Use   to browse sport content in the [On Now](#) carousel and press  to watch.



Optus Sport

Use   to scroll to the [Optus Sport](#) carousel and press  to watch. You need a subscription to Optus Sport to watch

Apps






The [Apps](#) carousel includes sport content on all the apps available on Fetch. You need a subscription to watch content on streaming services like Stan Sport and Paramount+.



YouTube Sport

The [YouTube Sport](#) carousel provides recommended sport videos on YouTube.

Team Recordings

Set Team Recordings to record all matches your team plays in (available for selected sporting events).


- 1 Select [Sport](#) from the main menu and press .
- 2 Use  to scroll down to the [Team Recordings](#) carousel and browse sport categories.
- 3 Press  to open the category screen. Use the competition tabs along the top of the screen to choose a competition.
- 4 Select a team and press  to display Team Recording options.
- 5 Change the options if you wish, then select [Confirm & Close](#) and press .






You can prioritise your Team Recordings at [Menu > My Stuff > Recording Priority](#) (see Page 22).

11 Watching live PPV events on TV

From time to time you can pay to watch live sports and entertainment events on TV. With Pay Per View (PPV) content, you'll make a one-off payment which lets you watch a purchased event on your Fetch box, mobile or tablet when it airs live on TV. You can't record a PPV event you have purchased. Replays of purchased PPV Events are available at [Menu > Apps > TV Apps](#) several hours after the conclusion of the PPV Event.






How to add a PPV event

- 1 Select [Add More](#) from the main menu.
- 2 Use  to see what's available and press  to select an event.
- 3 Press  to purchase the event. You'll need to enter your PIN to confirm the one-off payment.

Please keep in mind, you can't unsubscribe or cancel once you confirm the purchase of a PPV event - so you can't be refunded if you later decide you no longer want to watch the event.

To watch PPV



- 1 Go to [Menu > Guide](#).
- 2 Use  to find channel 970 for the event and press .
- 3 Choose [Watch](#) and press . If you haven't yet purchased the event, we'll prompt you to purchase it now.


12 Continue Watching from My Stuff

My Stuff is the easiest place to get back to what you were watching – anywhere on Fetch. As you watch shows and movies, add to My Stuff, or set recordings, they'll be added to [My Stuff](#) so you can easily jump back into them again.

Continue Watching carousel

The [Continue Watching](#) carousel in [My Stuff](#) keeps track of your recently watched items and includes Recordings, Free-to-Air TV Apps, and the Movies and Shows stores.

Use  to navigate and press  to resume.



Continue watching on another Fetch box

You can start watching in one room and resume playback on a connected Fetch box too. To set this up, go to [Menu > ⚙ > Multiroom > Options](#). For more info, download the Multiroom User Guide.

New Seasons and Episodes carousel

The [New Seasons and Episodes](#) carousel includes new episodes of shows you've watched.

Recent Recordings carousel

Includes your latest recordings. Select a recording to open it in [My Stuff > Recordings](#) (see Page 19).

Apps carousels

As you scroll down the [My Stuff](#) screen, you'll see carousels for each streaming app you're subscribed to, so you can continue watching these too. We currently have carousels for My Netflix, My Prime Video, My Stan and My Paramount+. If you use other streaming apps, you can use the [Recently Used](#) carousel for quick access.


For quick access to the TV Apps (like ABC iview and SBS On Demand) look for the [Free TV Apps](#) carousel.

My Purchases & Rentals, My Shows and My Movies

Access your recent movie and show purchases in the [My Stuff > My Purchases & Rentals](#) carousel.


To find all shows and movies you engaged with (watched, added to [My Stuff](#), purchased, or recorded) go to [My Stuff > My Shows](#) or [My Stuff > My Movies](#).

Shows and movies you've purchased through the [Store](#) on Fetch (Pages 26 and 31) will be flagged with a tick ✓.




13 Settings including Parental Controls

There are lots of things you can do in the Settings area at [Menu > ⚙️](#). Here we outline the most commonly used ones.




View your downloads

View all your downloading items, change the order of downloads or delete items.




Set up for channels

Access the Free-to-Air (FTA) frequency scan that identifies and tunes all visible channels. You can also add your favourite channels to your Favourites list or hide selected channels.




Optimise your sound and display

Select [Audio & Visual > Video](#) to optimise your TV screen display. To refine your video settings or turn on [HDR](#) (High Dynamic Range) if your TV supports this, choose [Advanced](#). In [Audio](#) you can turn on Surround Sound 5.1 if using a surround sound system. Select [Bluetooth](#) to pair headsets, speakers, or mobile devices. For more information see Page 52.







Mobile & Tablet

Find your Activation Code (also called Fetch ID) which you need to sign in to the Fetch Mobi App. Then you can control your Fetch Mighty like a remote control from your mobile device. See the Mobile App Guide at fetch.com.au/guides for more information.



Channel Locking

- 1 Use   to highlight the channel you wish to lock.
- 2 Press  which will prompt  next to the locked channel.
- 3 Repeat for all channels you wish to lock.
- 4 To remove locking from previously locked channels repeat the above steps.

Set Parental Lock



You can set the program ratings levels that can be viewed. Use  to select an option and press .

Never Lock means you won't need your PIN to watch. **Always Lock** means you'll always need your PIN to watch content at the set level. **Time Lock** lets you lock content between set times - such as MA+ programs between 6am and 9pm, when children may be watching.

App Locking


In the **Apps** settings you can **Lock** individual apps so you always need your PIN to launch them. Or you can choose **Allow** to launch an app without a PIN.

Change your Parental PIN



- 1 Select **PIN Change** in **User Preferences** and press .
- 2 Enter and confirm your new four digit PIN and press . You'll receive a confirmation if the PIN was updated successfully.



The same PIN is used across all Fetch boxes on your account and also phones and tablets on which you're using the Fetch Mobi App.



User Preferences

In the **User Preferences**, you can change recording options and change your PIN. Also find the Activation Code (also called Fetch ID) for your Fetch Mighty, or set up your TV Guide viewing options. Use  to select an option and press .

TV Guide

Set your TV Guide viewing options. You can show or hide program info in the TV Guide Grid View (see Page 12) to see more channels at a time.

View Options


Boost the lifetime of your Fetch Mighty by stopping Pause Live TV after 3 hours of viewing a channel. Autoplay lets the next episode of a show play automatically when watching recordings and TV shows.

Recording

Add a recording start and stop time to all your scheduled recordings, set a Season option for Series Recordings, or select the number of episodes you want to keep for all recordings. You can also set the rewind length to backtrack a program/recording when fast-forwarding at high speeds.

Streaming

Set the number of streamed channels you can record at a time. Only shown if your service includes streamed TV channels. The maximum number of channels will vary depending on your service.



Share content between your boxes

In the Multiroom settings you can turn on sharing so you can watch recordings on other Fetch boxes in your home. Choose another name for your box to make it easier to see which recordings you're watching (Page 20).


14 Pair a Bluetooth Device


You can pair your own devices, such as headphones, speakers, or mobile devices via Bluetooth to your Fetch Mighty. So, you can listen to Fetch without disturbing anyone else in the room via headphones, or play music from your phone on your Fetch Mighty and TV.

To pair a Bluetooth device

Power on your headphones, speakers, or mobile device and make sure the device is ready to pair. For mobile phones, remember to turn on Bluetooth in the device settings.

Go to [Menu > ⚙ > Audio & Visual > Bluetooth](#).

- 1 If needed, [Turn On](#) Bluetooth. Bluetooth will be on automatically if using a Bluetooth Remote to control your box (Page 56).
- 2 To pair a Bluetooth headset, choose [Send Audio](#).
- 3 To pair your mobile device, choose [Receive Audio](#).
- 4 Select  to scan for your device then choose the device name on the screen to pair.



Note


- Bluetooth pairing is only supported on the Fetch Mighty and Fetch Mini. It's not supported on Gen 2 boxes.
- You can't currently pair an Apple iPad to the Fetch box via Bluetooth.

Listen to Fetch through headphones or speakers

When listening to Fetch through Bluetooth headphones you can control the volume and pause or play from the device. When watching TV with others in the room you can listen to Fetch through **both** the headphones and TV. Select **TV Audio** in the Bluetooth settings. You can then change the volume on your headphones without affecting the box.


Send music to Fetch from your mobile phone

When you pair your phone to your Fetch Mighty via Bluetooth, you can pick songs from your music library or an app to play on your TV. Any audio you play from your phone – such as Snapchat, Instagram, YouTube, and Spotify – will play on your paired Fetch Mighty and TV.




Tips and help for Bluetooth

If you are having trouble using Bluetooth on Fetch to listen through headphones, speakers or smartphones, here are some things to try:

- 1 If you can't pair headphones or speakers to your Fetch box, check your Bluetooth device is in "pairing mode". On headphones this is typically shown by a flashing light.
- 2 Check if your Bluetooth headphones or speakers are paired to another device. If so, disconnect them from the other device then try to pair to your Fetch box again.
- 3 Make sure you're in range of your Fetch box and there's no interference from nearby devices like wireless speakers or cordless phones.
- 4 Make sure your Bluetooth device is fully charged, or try changing the batteries in the device. Try turning Bluetooth off and on or restarting your device to see if this helps.
- 5 Check for firmware updates on your Bluetooth device.
- 6 Check that you can pair your Bluetooth device to another device. If you can't, then you may need to seek help from your Bluetooth device manufacturer or documentation.
- 7 If you replace faulty Bluetooth headphones or speakers you were using with Fetch, you should 'forget' the device. Go to [Menu > ⚙ > Audio & Visual > Bluetooth](#) and press . This will stop the box from trying to pair to an old device.
- 8 If you can, turn off Bluetooth on your Fetch box when you're not using it. (So your device doesn't pair to your Fetch box whenever you're in range). Go to [⚙ > Audio & Visual > Bluetooth](#) and choose [Turn Off](#). If you've paired the Fetch Voice Remote via Bluetooth (Page 56) you can't turn off Bluetooth as the remote needs a Bluetooth connection for voice control.


15 The Remote Control


The remote control brings Fetch to life. It has all the functions you need for quick and easy viewing.




Tips

To set up this universal remote see “Fetch Remote 4” user guide.

Once universal remote is set up, to set Fetch remote to control the volume on your TV, press  and VOL+ simultaneously and wait for LED to blink once.



To set Fetch remote to control the volume on your Fetch Box, press  and VOL- simultaneously and wait for LED to blink twice.




Tips

To set up this universal remote, see “Fetch Remote 5” user guide.


Pair the remote to enable voice control and voice search.

To pair, hold down  and point the remote at your Fetch Mighty. For voice control, hold down  and speak into the microphone at the top of the remote (Page 6).

It may take a few button presses to re-connect to your Fetch Mighty.

Once universal remote is set up, to set Fetch remote to control the volume on your TV, go to **Menu >  > Remote Control** and choose **Set to TV**. To set Fetch remote to control the volume on your Fetch Box, choose **Set to Fetch**.

Note


The included remote varies depending on where you got your Fetch Mighty. If your remote looks different to the ones shown, you can refer to the remote instructions at fetch.com.au/remote or go to **Menu >  > Remote Control**. The Voice Remote is available for purchase at fetch.com.au/voice.

Set up for Universal Remote


You can use this remote control to operate your TV as well as your Fetch Mighty.

Fetch will try to set up your remote for you when you first set up your box but if that didn't work follow the steps below.

Remote 4

- 1 Press  and hold for 3 seconds until remote LED flashes twice. Your TV will now show a table of brands.
- 2 Press and hold the matching number on the remote control for your brand of TV.
- 3 As soon as TV turns off, stop pressing the remote. LED will blink twice. Your TV is now set up!

Remote 5 (Voice Remote)

- 1 Go to [Menu > ⚙ > Remote Control](#) and choose [Universal Setup](#).
If your remote isn't paired yet, choose [Pair Remote](#) and wait for the TV to confirm the remote is paired.
Repeat step 1.
Follow on screen to see what to do next.
- 2 If needed your TV will show a table of brands to choose from.
- 3 Your TV will ask you to test the volume buttons operate your TV volume too. Follow on screen by pressing the corresponding button on your remote.
If this works, confirm by pressing . Fetch may ask you to test other buttons too such as the Vol-, AV/Source, and TV Power, depending on your TV.

You'll see a confirmation on screen when your TV is set up.

Using a different Fetch remote?

If your Fetch remote control has different buttons to the one shown above or if your TV brand is not listed on screen when you follow the steps above, you will need to refer to the Universal Remote Set Up Guide on fetch.com.au or go to [Menu > ⚙ > Remote Control](#).



www.fetch.com.au

© Fetch TV Pty Limited. ABN 36 130 669 500. All rights reserved. Fetch TV Pty Limited is the owner of the trade marks Fetch. The set top box and the Fetch service may only be used lawfully and in accordance with relevant terms of use of which you are notified by your service provider. You must not use the electronic program guide, or any part of it, for any purpose other than private and domestic purposes and you must not sub-licence, sell, lease, lend, upload, download, communicate or distribute it (or any part of it) to any person.

Version: May 2023